




For extra heavy duty loading conditions with concrete floor units. To achieve loading figures, lintel must be built in with blockwork as shown.




For extra heavy duty loading conditions with concrete floor units. To achieve loading figures, lintel must be built in with blockwork as shown.



For extra heavy duty loading conditions with concrete floor units. To achieve loading figures, lintel must be built in with blockwork as shown.



For extra heavy duty loading conditions with concrete floor units. To achieve loading figures, lintel must be built in with blockwork as shown.



For extra heavy duty loading conditions with concrete floor units. To achieve loading figures, lintel must be built in with blockwork as shown.